

## 19 Series Exit Device Template Index Hollow Metal Door Applications

19 Series Device	Device Template
19-R, F-19-R	<a href="#">T-1100</a>
19-V, F-19-V, 19-V-LBR, F-19-V-LBR	<a href="#">T-1105</a>

19 Series Device	19 Series Trim	Trim Template
19-R, F-19-R, 19-V, F-19-V, 19-V-LBR, F-19-V-LBR	917DT, 930C, 930DT, 930NL, 930EO	<a href="#">T-2123</a>
19-R, F-19-R, 19-V, F-19-V, 19-V-LBR, F-19-V-LBR	920DT, 920NL	<a href="#">T-2124</a>
19-R, F-19-R, 19-V, F-19-V, 19-V-LBR, F-19-V-LBR	930DT narrow stile, 930NL narrow stile	<a href="#">T-2126</a>
19-R, F-19-R, 19-V, F-19-V, 19-V-LBR, F-19-V-LBR	911K, 912L	<a href="#">T-2190</a>
19-R, F-19-R, 19-V, F-19-V, 19-V-LBR, F-19-V-LBR	918DT, 918NL	<a href="#">T-2191</a>
19-R, F-19-R, 19-V, F-19-V, 19-V-LBR, F-19-V-LBR	913KIK, 914KIL	<a href="#">T-2131</a>

19 Series Device	19 Series Strike	Strike Template
F-19-R	F-570 (standard)	<a href="#">T-3001</a>
19-R, F-19-R	565	<a href="#">T-3006</a>
	571, 571-A	<a href="#">T-3003</a>
	490, F-490 (optional)	<a href="#">T-3001</a>
19-V, F-19-V, 19-V-LBR, F-19-V-LBR	3788 Top Strike with 4215 angle bracket (standard)	<a href="#">T-3032*</a>
19-V, F-19-V	2130 Bottom Strike (standard)	<a href="#">T-3053</a>
	2126-A Bottom Strike (optional)	<a href="#">T-3050</a>
19-V, F-19-V	4155 Bottom Strike (optional)	<a href="#">T-3055</a>

\* For F-19-V-LBR applications, add template [T-5494](#) for Auxiliary Fire Latch.